

Fitting Instructions

AC Schnitzer Footrest (LHD)

1.1 Components Supplied

1 AC Schnitzer Footrest

Black No.: 5171 10 70; 5171 32 71 or 5171 34 73

Aluminium No.: 51 48 36 05 or -06; 5148 32 05 or 5148 34 05

Carbon fibre No.: 5171 36 10

4 Plastic pins

4 cross-head screws $\varnothing 3,5 \times 16 \text{ mm}$

1.2 Tools Required

Electric drill bit and 2,5mm bit

Cross-head screwdriver

Marking pen

2. Fitting

- Place the AC Schnitzer footrest in the car, align and mark the fixing points at the top (1) and bottom (2) through the holes in the tabs.
- Remove footrest again.
- At the bottom points marked, using a cross-head screwdriver make a hole approx. 5 mm diameter in the carpet and insert or screw the carpet pins supplied into the holes.
- At the upper points marked, drill a 2,5mm hole (for vehicles where the carpet extends further up, make the upper fixing points in the same way as the lower ones).
- Replace the AC Schnitzer footrest and screw in place with the $\varnothing 3,5 \times 16 \text{ mm}$ cross-head screws supplied.

