

# Fitting Instructions

**AC  
SCHNITZER**

## AC Schnitzer Aluminium Pedal Set E38 / E39

### 1.1 Components Supplied

- 1 AC Schnitzer aluminium pedal set including rubber underlays No. 5147 38 05; -06 and 5147 39 05; -06
- 12 allen bolts M3 x 15 mm
- 12 washers
- 12 self-locking nuts A/F 5,5 mm
- 1 standard gas pedal

### 1.2 Tools Required

- Electric drill and 3,5 mm bit, allen key 2,5 mm
- Open-ended spanner 5,5 mm
- Marking pen

### 2. Fitting

- Remove the standard pedal rubbers from the clutch and brake pedal, then lever out the standard gas pedal from its lower fixing in the vehicle floor and release the upper end from its fixing; to do this, remove the bolts from the gas pedal holder and remove the gas pedal.
- Place the AC Schnitzer aluminium pedals on the clutch and brake and position the new gas pedal supplied, align and mark the fixing points through the existing holes in the AC Schnitzer pedals ( 1 ).
- Remove the AC Schnitzer aluminium pedals again and drill a 3,5 mm hole at the points marked on the standard pedals.
- Insert the rubber underlays supplied into the AC Schnitzer aluminium pedals from the rear.
- Place the AC Schnitzer aluminium pedals on the brake and clutch, fit the new gas pedal, insert the allen bolts supplied in the fixing points, attach the nuts and washers supplied on the back and tighten.
- Replace gas pedal; to do this, insert the bolts in the gas pedal holder and clip the lower end of the pedal into the holder on the vehicle floor.

